

e2v

e2v

Linux Embedded applications in Machine Vision

Embedded Linux Conference – Europe (Grenoble)
October 15th, 2009

Pascal PELLET

e2v

e2v presentation



Machine Vision



GigE Vision protocol



e2v GigE Vision IP



Conclusion & Evolution



e2v presentation: Product Offer



e2v

Medical, Industrial & Emerging Imaging


Medical



Cameras




CMOS
sensors



CCD sensors

Mixed Signal ASICs

Sensor
Signal conditioning
ICs




Space & Scientific Imaging

Space




Scientific
Imaging



Converters & Microprocessors

Broadband
Data Converters



Assembly & Test services

e2v presentation Fields of application



e2v

Aerospace



Defence



Automotive



Industrial Imaging



Telecom



Instrumentation



Medical



Industrial



e2v

e2v presentation



Machine Vision



GigE Vision protocol



e2v Gige Vision IP



Conclusion & Evolution



Machine Vision application



e2v

→ For industrial market, e2v semiconductors is a world leader in development and manufacturing of camera for Machine Vision




Machine Vision application



e2v

→ System based on cameras and acquisition systems (frame grabber, PC, ...)





Machine Vision application



e2v

→ Used in industry for

- Foods (sort rice, fruit inspection,...)
- Checking goods (web, papers, wood, glass, flat panel)



Machine Vision application



e2v

→ e2v, with other Machine Vision companies, contributes to the development of industrial standards, including:

→ Camera Link



→ GigE Vision



→ Genlcam standard for software access



e2v presentation

e2v

e2v presentation



Machine Vision



GigE Vision protocol



e2v GigE Vision IP



Conclusion & Evolution



GigE Vision protocol: Overview



e2v

- GigE Vision® is a camera interface standard developed, based on Ethernet protocol.
- Main benefits
 - fast image transfer: High bandwidth (1000 Mbps) allows large uncompressed images to be transferred quickly in real time
 - low cost standard cables over very long lengths (100 meters)
 - Data transfer up to Standard gigabit Ethernet hardware allows single/multiple camera connection to single/multiple computers
- This protocol is managed by AIA (Automated Imaging Association)
 - www.machinevisiononline.org
- e2v is a member of the Gige Vision development committee with other companies:
 - NI, Matrox, Pleora ...




GigE Vision protocol: Overview



e2v

→ GEV Protocol

- GVCP: GigE Vision Control Protocol
- GVSP: GigE Vision Stream Protocol
- GEV is based on different phases
 - IP address allocation
 - Discovery
 - Connection
- These protocols use UDP IPv4 as the transport Layer Protocol



→ Device description

- An xml file describes all the device capabilities (compliant with the GenICam specification)
 - One register corresponds to one feature
 - Understandable by any GenIcam PC software to monitor the camera

GigE Vision protocol: GigE Vision Control Protocol (GVCP)



e2v

- GVCP is an application layer protocol relying on the UDP transport layer protocol
- GVCP provides a set of commands and acknowledges messages to be exchanged between GEV device(s) (camera) and a GEV application(s) (host)
 - Read/write Register
 - Read/Write Memory
 - Discovery
- Asynchronous Message can be sent by the device: event
- GVCP packet:


Layer	Size
IP header	20
UDP header	8
GVCP header	8
Max GVCP Payload	540
Total	576

GigE Vision protocol: GigE Vision Stream Protocol (GVSP)



e2v

- GVSP is an application layer protocol relying on the UDP transport layer protocol.
- It allows an application to receive data blocks from a device.
- A data block is divided into 3 elements:
 - Data leader : advises the host of the beginning of the data block
 - Data Payload : data
 - Data Trailer : advises the user the end of the data block
- Payload types:
 - Image
 - Raw data
 - File
 - Chunk data
 - Device Specific



e2v

e2v presentation



Machine Vision



GigE Vision protocol



e2v GigE Vision IP



Conclusion & Evolution



e2v GigE Vision IP: e2v Generic platform





e2v

→ In order to develop a camera supporting GigE Vision, e2v has developed a generic platform based on:

→ ARM processor (Atmel AT91SAM9263)

→ Linux v2.6.24



e2v GigE Vision IP: Base bricks to products



e2v


→ New base bricks: → New products:

→ Camera link IP → Camera Link LineScan Camera:

→ AviivA EM2CL – AviivA EM4CL

→ 160 Mpixels/sec

→ Mono8-12bit



→ GigE Vision IP → GigE Vision LineScan Camera :

→ AviivA EM1GE

→ 120 MPixels/sec


→ Mono8/12bit



→ Characterization IP → Characterization boards (internal use)

→ CCD and CMOS Imaging sensors

→ ADC ...



e2v GigE Vision IP: fixe issues



e2v

- e2v fixed issues for its products:
 - Upgradable
 - Reliability
 - Reduce the development time

e2v GigE Vision IP: Benefits



e2v

→ What does this platform bring for e2v products


- Project
 - Re-use
 - Cost Saving
 - Reliability / Improvement
- Development flow
 - Support and knowledge
 - Validation and testability
 - C++ (abstraction, coding efficiency)
- Linux services
 - TCP/IP Stack
 - PPP
 - File system management
 - ARP
 - Multi thread

e2v GigE Vision IP Architecture



e2v

→ e2v develops a GigE Vision IP based on this generic platform and a FPGA



e2v


-

e2v GigE Vision IP: Ethernet driver



e2v

- Configures the PHY
- Interfaces with the FPGA
- Configures the FPGA (Mac Address ...)
- Copies packets from FPGA RX FIFO to the TCP/IP stack
- Copies packets from TCP/IP stack to the TX FIFO




e2v GigE Vision IP: GEV driver



e2v

→ Access to FPGA GEV Registers




e2v GigE Vision IP: EthernetTL library



e2v

- Loads the FPGA
- Mounts the Ethernet driver
- Sets Mac address




e2v GigE Vision IP: GigE Vision Library (libGEV)



e2v

- Offers all GigE Vision based features
- Mounts the Ethernet connection (through ethernetTL)
- IP address Allocation
- Discovery
- Read/Write memory/register
- GEV registers configuration



e2v

e2v presentation



Machine Vision



GigE Vision protocol



e2v Gige Vision IP



Conclusion & Evolution



Conclusion & Evolution Performance



e2v

- For the control, the gigabit per second is not required.
 - Max speed: 30Mbit/sec
 - To improve speed:
 - Use DMA to read/write into FPGA FIFOs

- For the streaming the gigabit is required
 - Max transmission speed 984Mbit/sec

Conclusion & Evolution Performance



e2v

- Software Interoperability
 - With the main GEV application software
 - National Instrument
 - Matrox
 - GigE Vision compliant
- Reliability
 - Memory allocation
 - Temperature

Conclusion & Evolution



e2v

→ Other GigE Vision applications:

→ Medical: X-ray application



→ Evaluation kit/characterization board for image sensors



→ Spectrometry :Swifts (Minalogic project)



→ Smart camera (no real time processing)

→ Gain control

→ Light control

Conclusion & Evolution



e2v

- Next: 10 gigabit Ethernet
 - Optical fiber
 - Copper wire

- Power Over Ethernet
 - video surveillance



Any Question ???